

# Setup Sheet Report

**REVISION: A** 

# **ROUTER DEFAULT**

# **GENERAL INFORMATION**

PROJECT NAME: ABC Test Project

CUSTOMER NAME: ABC Manufactoring Company


PROGRAMMER: Mick George

DRAWING: 12345

DATE: Tuesday, May 23, 2017

TIME: 3:55 PM

#### C:\USERS\PUBLIC\DOCUMENTS\SHARED





	2.0366	in
,	Inch	

COMMENTS			

# C:\USERS\MG\DOCUMENTS\MY MCAM2019\ROUTER\NCI\T.NCI

CYCLE TIME: 0 HOURS, 2 MINUTES, 45 SECONDS

## **OPERATION LIST**

OPERATION INFO 1 - Contour (2D)


CYCLE TIME: COMMENT:

0 HOURS, 0 MINUTES, 14 SECONDS

PROGRAM NUMBER: 0

SPINDLE SPEED: 18000 RPM FEEDRATE: 200.0 inch/min

CLEARANCE PLANE: 2.0
RETRACT PLANE: 0.25
FEED PLANE: 0.1
DEPTH: 0.0
STOCK TO LEAVE: 0.0
COMP TO TIP: NO
WORK OFFSET: -1




#### TOOL INFO 1/4 STRAIGHT BIT

TYPE: Straight NUMBER: 1 DIAMETER: 0.25 0.0 CORNER RADIUS: LENGTH OFFSET: 1 DIAMETER OFFSET: 1 MATERIAL: HSS NUMBER OF FLUTES: 2

FPT: 0.005 SFM: 1308.9005

MFG CODE: ASSEMBLY:

HOLDER: Default Holder TIME: 00:00:14



#### OPERATION INFO 2 - Router Block Drill - Drill/Counterbore

CYCLE TIME: 0 HOURS, 2 MINUTES, 30 SECONDS COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 1000 RPM FEEDRATE: 10.0 inch/min

CLEARANCE PLANE: 2.0
RETRACT PLANE: 10.0
FEED PLANE: 0.25
DEPTH: 0.0
STOCK TO LEAVE: 0.0
COMP TO TIP: NO
WORK OFFSET: -1



0

0

0

0

#### BLOCK INFO #2 - BLOCK DRILL -

OFFSET: 0.0, 0.0, 0.0

COMMENT:

TIME: 00:02:30

#2 - 0.2500 DRILL - STANDARD DRILL
OFFSET: 0.0, 0.0, 0.0
AGG: NO
#2 - 0.2500 DRILL - STANDARD DRILL
OFFSET: 1.2598, 0.0, 0.0
AGG: NO
#2 - 0.2500 DRILL - STANDARD DRILL
OFFSET: 2.5196, 0.0, 0.0
AGG: NO
#2 - 0.2500 DRILL - STANDARD DRILL
OFFSET: 3.7794, 0.0, 0.0
AGG: NO
#2 - 0.2500 DRILL - STANDARD DRILL
OFFSET: 5.0392, 0.0, 0.0
AGG: NO
#2 - 0.2500 DRILL - STANDARD DRILL
OFFSET: 0.0, -1.2598, 0.0
AGG: NO
#2 - 0.2500 DRILL - STANDARD DRILL
OFFSET: 0.0, -2.5196, 0.0
AGG: NO
#2 - 0.2500 DRILL - STANDARD DRILL
OFFSET: 0.0, -3.7794, 0.0
AGG: NO
#2 - 0.2500 DRILL - STANDARD DRILL
OFFSET: 0.0, -5.0392, 0.0
AGG: NO
#2 - 0.2500 DRILL - STANDARD DRILL
OFFSET: 0.0, -5.0392, 0.0
AGG: NO



TOOL LIST Sorted: NO

## TOOL INFO 1/4 STRAIGHT BIT


TYPE: Straight
NUMBER: 1
DIAMETER: 0.25
CORNER RADIUS: 0.0
LENGTH OFFSET: 1
DIAMETER OFFSET: 1
MATERIAL: HSS
NUMBER OF FLUTES: 2

FPT: 0.005 SFM: 1308.9005

MFG CODE: ASSEMBLY:

HOLDER: Default Holder

TIME: 00:00:14



0

0

0

(1)

0

AGG: NO

(4)

(1)

(#)

USED BY OPERATION: #1 1 - Contour (2D)

### BLOCK INFO #2 - BLOCK DRILL -

OFFSET: 0.0, 0.0, 0.0

COMMENT:

TIME: 00:02:30

#2 - 0.2500 DRILL - STANDARD DRILL OFFSET: 0.0, 0.0, 0.0 AGG: NO

#2 - 0.2500 DRILL - STANDARD DRILL OFFSET: 1.2598, 0.0, 0.0 AGG: NO

#2 - 0.2500 DRILL - STANDARD DRILL OFFSET: 2.5196, 0.0, 0.0 AGG: NO

#2 - 0.2300 DIVILE - STANDARD DIVILE OF TSET. 2.3190, 0.0, 0.0 AGG. NO

#2 - 0.2500 DRILL - STANDARD DRILL OFFSET: 3.7794, 0.0, 0.0 AGG: NO

#2 - 0.2500 DRILL - STANDARD DRILL OFFSET: 5.0392, 0.0, 0.0 AGG: NO

#2 - 0.2500 DRILL - STANDARD DRILL OFFSET: 0.0, -1.2598, 0.0 AGG: NO

#2 - 0.2500 DRILL - STANDARD DRILL OFFSET: 0.0, -2.5196, 0.0 AGG: NO

#2 - 0.2500 DRILL - STANDARD DRILL OFFSET: 0.0, -5.0392, 0.0 AGG: NO

USED BY OPERATION: #2 2 - Router Block Drill - Drill/Counterbore

#2 - 0.2500 DRILL - STANDARD DRILL OFFSET: 0.0, -3.7794, 0.0

#### **WORK OFFSETS**

#### OFFSET INFO

NUMBER: -1 PLANE: ORIGIN: 0.0, 0.0, 0.0

USED BY OPERATION: #1 1 - Contour (2D)

USED BY OPERATION: #2 2 - Router Block Drill - Drill/Counterbore